

# TECNOLUMEN

---

TECNOLUMEN GmbH & Co. KG • Lötzeener Str. 2-4 • D-28207 Bremen • Tel (0421) 430 41 70 • Fax (0421) 4986685

---

## Assembly instructions and important information WG 27/28

### **Technical details:**

Power supply: 110-240 V / 50-60 Hz

Bulb socket: E27

Protection class: I

Maximum wattage (thermal):

60 W

Recommended bulbs:

energy-saving bulb 11 W

#### **Note:**

This specified maximum wattage applies to conventional bulbs. Since these have however been off the market since 01.09.2009, we recommend energy-saving bulbs with about 1/5 of the specified wattage.

**Halogen bulbs are not suitable** because these become much hotter than conventional bulbs.

### **Safety instructions:**

- Never cover the luminaire with a cloth – fire hazard!
- Always ensure that the plug is removed from the socket before working on the luminaire or changing the bulb.
- Have repair work performed only by an authorized electrician, because electrical power can cause severe injuries!
- Please note the specified maximum wattage of the bulbs.

**Fitting too strong a bulb may lead to discolouring  
of the lampshade and fire hazard!**

### **Care of lamp:**

Use a standard commercial cleaner for the glass parts.

In the course of time a silver-colored patina forms on the nickel plated metal parts, which is frequently desired. If you want him surface to retain a glossy nickel-plated finish for reasons of appearance, use a polish without abrasive agents.

Clean the upper side of the lampshade using a dry cloth and without exerting any pressure. The inside of the lampshade can be cleaning with a damp cloth.

### **Mounting the lampshade:**

Turn the upper retaining ring off the light base. Put the lower part of lampshade and the lampshade onto the lower retaining ring. Then screw the upper retaining ring on again.

Please note the leaflet enclosed with the lampshade:

**“Important information on the lampshades”**